Assembly Instructions


T2-NP100S--0

SOFA TABLE

PARTS LIST

PART NO	FIGURE	DESCRIPTION	QTY
T2-NP100S-01		Hardware Bag	1 pce
T2-NP100S-13		Table Top	1 pce
T2-NP100S-15		Trestle Base	2 pcs
T2-NP100S-22		Fixed Shelf	1 pce

IMPORTANT NOTE: Please keep all hardware parts out of the reach of children.



Assembly Instructions

T2-NP100S--0

Reminders:

SOFA TABLE

Two people are needed for assembly.


Use only hardware supplied.

Do not over tighten bolts.

This item may require periodic tightening.

8 pcs

HARDWARE PART:







8 pcs

Wood Button


8 pcs



ASSEMBLY:


STEP 1

Turn the Table Top upside down on a protective surface such as carpet or other soft material. Attach the Trestle Base to the Top Table by inserting the wood dowel into the pre-drilled holes on the Trestle Base. Attach **Flat Washer**, **Lock Washer** and **JCBC Bolt** by using




STEP 2

Insert the Fixed Shelf into the Trestle Base and then insert another one Trestle Base by inserting the wood dowel into the pre-drilled holes on the Trestle Base. Attach **Flat Washer,Lock Washer** and **JCBC Bolt** by using **Allen Key** provided.



STEP 3

Check its balance and tighten all bolts, Insert wood plug into the bolt holes on trestle to complete the assembly.



IMPORTANT NOTE:

~ Please keep all hardware out of the reach of children.

CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistenly. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.