Thank You for purchasing this Quality product. It has been engineered for easy assembly yet constructed for durability. Please take the time to read and follow the instruction while assembling.

ASSEMBLY INSTRUCTIONS


AVERY UPHOLSTERED SIDE CHAIR Model: C1-AV104S--0 (C-1505 RTA)


Size: 21" X 18" X 44"H

Step 2

* POWER TOOLS ARE NOT RECOMMENDED.


List of Part For 1 Set





List of hardware For 1 Set

Code	Figure	Hardware	Qty.
(a)		Hex.Bolt M6 x 80mm	4
Э		Hex.Bolt M6 x 60mm	4
©		Hex.Bolt M6 x 40mm	2
(d)	0	Flat Washer	10
(e)	0	Spring Washer	10
Ð	5	Spanner 10mm	1






- Keep all hardware parts out of reach of children.
- * Must tighten screws periodically. With use screws will become loose. Check tightness of all screws every 6-8 weeks.
- * Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatedly.
- * Do not tighten all screw / bolt until all completely assembled.

Notes

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials including staples & packing straps before you start to assemble.

Care And Maintenance

- The Touch of a soft cloth is all the maintenance
- your wood pieces will ever need. Never use harsh chemicals or abrasive cleaner as
- they could mark or destroy finish.



PAGE 1 OF 1