# **Assembly Instructions**


#### **T2-Q100EN**

**SOLID R/W END TABLE** 

### **PARTS LIST**

PART NO	FIGURE	DESCRIPTION	QTY
<b>T2-Q100EN</b> -01		Hardware Bag	1 pce
<b>T2-Q100EN</b> -13		Table Top	1 pce
<b>T2-Q100EN</b> -07	<b>←</b>	Legs	4 pcs
<b>T2-Q100EN</b> -22		Fixed Shelf	1 pce

**IMPORTANT NOTE:** Please keep all hardware parts out of the reach of children.




## **Assembly Instructions**

### **T2-Q100EN**SOLID R/W END TABLE

#### Reminders:

Two people are needed for assembly.
Use only hardware supplied.
Do not over tighten bolts.
This item may require periodic tightening.


#### **HARDWARE PART:**




#### **ASSEMBLY:**


#### STEP 1

Turn the Table Top upside down on a protective surface such as carpet or other soft material. Place the three legs to the corner of the apron then insert the **Flat Washer**, **Lock Washer** and **JCBC Bolt** into pre-drilled holes on the corner block and tighten it by using the **Allen key** provided. Insert the Fixed Shelf into the assembly legs as shown in the diagram, then install the fourth leg by use **Flat Washer**, **Lock Washer** and **JCBC Bolt** into pre-drilled holes on the corner block and tighten it by using the **Allen key** provided. Continue by using the **Flat Washer**, **Lock Washer** and **JCBC Bolt** into pre-drilled holes on the corner block of Fixed Shelf and by using the **Allen key** provided.





**STEP 2**Check its balance and tighten all bolts to complete the assembly.



#### **IMPORTANT NOTE:**

~ Please keep all hardware out of the reach of children.

#### **CARE INSTRUCTION**

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.